

SERVICE BULLETIN



BULLETIN #: SB053116A

CONDITION: Ojeda Freezer compressor upgrade requires a change in the Power Box Main Fuse.

CORRECTIVE ACTION: Recommended

KIT NAME / MODIFICATION: Evolution Vendor with Ojeda Freezer - Power Box Fuse Upgrade

APPLIES TO: Evolution Models with Ojeda Freezers.

Caution: (High Voltage Machine 110VAC) Always observe all safety precautions and manufacturer recommendations when servicing

TOOLS / SUPPLIES REQUIRED:

15A fuse (supplied), 2 replacement stickers (supplied)

PROCEDURE:

1. Turn "OFF" machine at the Power Box Rocker Switch and unplug the machine from the wall outlet. Make sure that lights and all other machine electronics are off.



2. Push down gently on the fuse holder, twist counter clockwise and lift out.



Pull the fuse straight out of the holder and insert the 15A replacement that had been provided by Fastcorp.

3. Insert the fuse holder back into it's receptacle, push down and gently twist clockwise $\frac{1}{4}$ turn until it locks into place.
4. Peel the backing material off of the new, 15A labels that have been provided and place them over the existing labels.

